

Dusk Pendant & Small Dusk Pendant - DK(na) & SDK(na)



studio haran

**Please read the instructions carefully before using this product.
Your light fitting should be installed by a qualified electrician.**

Caution: Please ensure electricity supply is switched off before installing the light.

Installation instructions:

1. Switch off electricity supply. Before making any electrical connections ensure the metal lamp holder (A) is connected to the cable and parts are fed on in the following order:
 - i. E26 lamp holder (A)
 - ii. ceiling rose (C)
2. Slide the ceiling rose along the cable until you have a suitable drop length for your space. Tighten the cable grip fully from the inside of the ceiling rose to fix the cable at this length.
3. You can now cut off the excess cable ensuring you leave enough cable left to make electrical connections.
4. Attach the metal bracket (E) to the junction box using the 8-32 screws supplied.
5. Using a terminal block (not included) make the appropriate electrical connections. The white wire is neutral, the black is live and the green is earth. The ends of the lighting cable should be prepared by removing the fabric braided outer and white insulating layer by 40mm, each of the inner cores should have their coloured insulating layer stripped back by 10mm, revealing the stranded copper core. The terminal block can remain inside the ceiling rose without being fixed.
6. The E26 lamp holder (A) and metal bracket (E) must be earthed.
7. Once all electrical connections are complete the connections and wires can be pushed into the junction box or remain within the ceiling rose.
8. The ceiling rose (C) can now be screwed into the bracket (E) with the 2 x m4 screws provided.
9. Remove the bottom shade ring (H), feed the ceramic shade over the lamp holder, return the bottom shade ring to the lamp holder and screw it on until the ceramic shade is secured.
10. With everything switched off you can now screw in your E26 light bulb (25W max, not included).

Maintenance and Care

Before conducting any maintenance, ensure light is switched off.

- Before replacing a defective bulb turn off the light at the switch and let the bulb cool down for at least 10 minutes
- Only change the bulb if it has completely cooled down. Use a clean cloth to help replace the bulb and try to avoid touching the glass with bare hands.
- If necessary the pendant light can be cleaned using a slightly damp cloth. Do not immerse in water.
- The pendant light is designed for indoor use only.
- If the external flexible cable or cable is damaged it shall be replaced by a qualified electrician in order to avoid a hazard.
- Young children should be supervised at all times to ensure they do not play with appliances.
- Position the cable so it will not become a hazard.

Technical Specifications

- Voltage: 110-220V 60Hz
- Rated Power: 25W Max
- Bulb Type: E26 Max 25W bulb (not included)
- Ingress Protection: IP20
- Cord length : Approx 1.5m
- Dimmable when used with a suitable bulb and switch
- Brass Ceiling Rose
- Ceramic Lampshade, Brass E26 Lampholder



Dusk Pendant Light Assembly

