

Element Flush/Wall Light - EF-O



Please read the instructions carefully before using this product.
Your light fitting should be installed by a qualified electrician.

Caution: Please ensure electricity supply is switched off before installing the light.

Installation instructions:

1. Switch off the electricity supply.
2. Attach the metal bracket (E) to the wall/ceiling using the supplied 2 x 4x40mm screws and plugs. If mounting to wall, ensure the metal bracket (E) is level.
3. Using a 3 pole terminal block (minimum rating 4A, 250V, not included) make the appropriate electrical connections. The brown wire is live, the blue is neutral and the yellow and green is earth. A screwed or screwless 3 terminal block with a minimum rating of 4A and 250V, should be used. The terminal block used must conform with IEC 60998-2-1 or IEC 60998-2-2. The ends of the lighting cable should be prepared by removing the fabric braided outer and white insulating layer by 40mm, each of the three inner cores should have their coloured insulating layer stripped back by 10mm, revealing the stranded copper core. The terminal block can remain inside the ceiling rose without being fixed.
4. Earth the metal lamp holder (A) and metal bracket (E).
5. Once electrical connections are complete, push the connections and wires into the wall cavity or leave them within the wall/ceiling bracket.
6. Screw the wooden wall/ceiling bracket (J) into the metal bracket (E) using the provided M4 screws.
7. With the wooden wall/ceiling bracket (J) secured, unscrew the metal shade ring (H) from the lampholder.
8. Place the ceramic shade (F) onto the lamp holder (A), followed by the oak collar (G) and secure it by screwing on the metal shade ring (H).
9. Ensure the ring is tight enough to hold the shade securely, but avoid over tightening to prevent damage.
10. Screw in your E27 light bulb (25W max, not included).

Maintenance and Care

Before conducting any maintenance, ensure light is switched off.

- Before replacing a defective bulb turn off the light at the switch and let the bulb cool down for at least 10 minutes
- Only change the bulb if it has completely cooled down. Use a clean cloth to help replace the bulb and try to avoid touching the glass with bare hands.
- If necessary the light can be cleaned using a slightly damp cloth. Do not immerse in water. If the oak looks dry, applying a clear wood polish, such as a beeswax polish, every 6 months will keep your lamp looking great for years to come.
- The wall light is designed for indoor use only.
- If the external flexible cable or cord is damaged it should be replaced by a qualified electrician in order to avoid a fire hazard.
- Young children should be supervised at all times to ensure they do not play with appliances.

Technical Specifications

- Voltage: 220-240V 50Hz
- Rated Power: 25W Max
- Bulb Type: E27 Max 25W bulb (not included)
- Ingress Protection: IP20
- Dimmable when used with a suitable bulb and switch
- Wooden Ceiling Rose & Collar, Ceramic Lampshade, Brass E27 Lampholder



Element Flush Assembly

