

Towan Flush/Wall Light - TW



Please read the instructions carefully before using this product.
Your light fitting should be installed by a qualified electrician.

Caution: Please ensure electricity supply is switched off before installing the light.

Installation instructions:

1. Switch off the electricity supply.
2. Attach the metal bracket (E) to the wall/ceiling using the supplied 2 x 8-32 screws. If mounting to wall, ensure the metal bracket (E) is level.
3. Using a terminal block (not included) make the appropriate electrical connections. The white wire is neutral, the black is live and the green is earth. The ends of the lighting cable should be prepared by removing the fabric braided outer and white insulating layer by 40mm, each of the inner cores should have their coloured insulating layer stripped back by 10mm, revealing the stranded copper core. The terminal block can remain inside the ceiling rose without being fixed.
4. Earth the metal bracket (E).
5. Once electrical connections are complete, push the connections and wires into the junction box or leave them within the wall/ceiling bracket.
6. Screw the wooden wall/ceiling mount (J) into the metal bracket (E) using the provided M4 screws.
7. With the wooden wall/ceiling bracket (J) secured, unscrew the shade ring (H) from the lampholder.
8. Place the shade (F) onto the lamp holder (A) and secure it by screwing on the shade ring (H).
9. Ensure the ring is tight enough to hold the shade securely, but avoid overtightening to prevent damage.
10. Insert your G9 light bulb (10W max, not included).
11. Screw the glass bulb cover (K) onto the G9 fitting, do not over tighten.

Maintenance and Care

Before conducting any maintenance, ensure light is switched off.

- Before replacing a defective bulb turn off the light at the switch and let the bulb cool down for at least 10 minutes
- Only change the bulb if it has completely cooled down. Use a clean cloth to help replace the bulb and try to avoid touching the glass with bare hands.
- If necessary the light can be cleaned using a slightly damp cloth. Do not immerse in water. If the oak looks dry, applying a clear wood polish, such as a beeswax polish, every 6 months will keep your lamp looking great for years to come.
- The wall light is designed for indoor use only.
- If the external flexible cable or cord is damaged it shall be replaced by a qualified electrician in order to avoid a fire hazard.
- Young children should be supervised at all times to ensure they do not play with appliances.

Technical Specifications

- Voltage: 110-220V 60Hz
- Rated Power: 10W Max
- Bulb Type: G9 Max 10W bulb (not included)
- Ingress Protection: IP20
- Dimmable when used with a suitable bulb and switch
- Wooden Wall bracket, Ceramic/Wooden Shade, Plastic Lampholder, Glass Bulb Cover





studio haran

Towan Flush/Wall Light Assembly

